GASTEC Instructions for No.142L Butyl Acetate Detector Tube

FOR SAFE OPERATION:

Carefully read this manual and the instruction manual of your Gastec Gas Sampling Pump.

⚠ WARNING:

- 1. Use only Gastec detector tubes in a Gastec Pump.
- Do not interchange or use non-Gastec parts or components in Gastec's detector tube and pump system.
- 3. The use of non-Gastec parts or components in Gastec's detector tube and pump system, or use of a non-Gastec detector tube with a Gastec pump, or use of a Gastec detector tube with a non-Gastec pump may result in property damage, serious bodily injury, and death; voids all warranties; and voids all performance and data accuracy guarantees.

⚠ CAUTION : If you do not observe the following precautions, you may suffer injuries or damage the product.

- 1. When breaking the tube ends, keep away from eyes.
- 2. Do not touch the broken glass tubes, pieces or reagent with bare hand(s).
- 3. The sampling time represents the time necessary to draw the air sample through the tube. The tube must be positioned in the desired sampling area for the entire sampling time or until the flow finish indicator indicates the end of the sample.

△NOTES: For maintaining performance and reliability of the test results, observe the following.


- Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
- 2. Use this tube within the temperature range of 0 40°C (32 104°F).
- 3. Use this tube within the relative humidity range of 0 90%. (When the dehumidifying layer is broken through the detecting reagent changes colour to orange.)
- This tube may be interfered with by the coexisting gases. Please refer to the table "INTERFERENCES" below.
- 5. Shelf life and storage condition of the tube are marked on the label of the tube box of tube.

APPLICATION OF THE TUBE:

Use this tube for detecting Butyl acetate in the air or in industrial areas and for determining the environmental atmospheric condition.

SPECIFICATION:

(Because of Gastec's commitment to continued improvement, specifications are subject to change without notice.)



Measuring Range	10 – 300 ppm
Number of Pump Strokes	2
Correction Factor	1
Sampling Time	1.5 minutes per pump stroke
Detecting Limit	2 ppm (n=2)
Colour Change	Yellow → Blackish brown → Pale blue after few minutes
Reaction Principle	$CH_3CO_2(CH_2)_3CH_3 + Cr^{6+} + H_2SO_4 \rightarrow Cr^{3+}$

Coefficient of Variation: 10% (for 10 to 300 ppm)

** Shelf Life: Please refer to the validity date printed on the box of tubes.

** Store the tubes in a cool and dark place.

CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE:

Temperature: Correct for temperature by the table below.

Tube	True Concentration (ppm)								
Reading (ppm)	0 °C (32°F)	5 °C (41°F)	10 °C (50°F)	15°C (59°F)	20°C (68°F)	25°C (77°F)	30°C (86°F)	35°C (95°F)	40°C (104°F
300	_	2150	1100	580	300	210	180	150	130
200	2000	1300	650	380	200	155	145	115	105
100	650	520	230	150	100	90	80	70	65
50	160	130	70	60	50	46	43	39	35
30	90	50	40	35	30	25	22	20	17
10	16	13	12	11	10	9	8	6.5	5

Humidity: No correction is required between 0 - 90% R.H. **Pressure:** To correct for pressure, use the formula below

Tube Reading* (ppm) × 1013 (hPa)
Atmospheric Pressure (hPa)

* This value is after other correction(s), if any, are applied.

MEASUREMENT PROCEDURE:

- For checking the leakage of the pump, insert a fresh sealed detector tube into the pump.
 Follow instructions provided with the pump operating manual.
- 2. Break tips off a fresh detector tube with the tube tip breaker of the pump.
- 3. Insert the tube into the pump inlet with arrow () on the tube pointing toward pump.
- Make certain the pump handle is all the way in. Align the guide mark on the pump body with the guide mark on the handle.
- Pull the handle all the way out until it locks at one pump stroke (100 mL). Wait 1.5 minutes and confirm the completion of the sampling. Repeat the above sampling procedure one more time.
- Read concentration level at the interface where the stained reagent meets the unstained reagent.
- If temperature correction is necessary, obtain the true concentration by using the temperature correction table.
- 8. If pressure correction is necessary, use the pressure correction formula.

INTERFERENCES:

Substance	Interference	Changes colour by itself to		
Alcohols (methanol)	+	Pale blue (≥ 5 ppm)		
Ketones (acetone)	+	Blackish brown (≥ 10 ppm)		
Esters (methyl acetate)	+	Blackish brown (≥ 30 ppm)		
Aromatic hydrocarbons (benzene)	No (The undiscoloured part of reagent changes colour to light brown.)	Pale brown for whole layer (≧ 30 ppm)		
Aromatic hydrocarbons (toluene)	+	Blackish brown (≥ 1 ppm)		

This table of interference gases primarily expresses the interference of each coexisting gas in the gas concentration range, that is equivalent to the gas concentration. Therefore, the test result may give a positive result from other substances not listed in the table. If more information is needed, please contact us or your Gastec representatives.

APPLICATION OF OTHER SUBSTANCES:

Tube 142L can also be used for the other substances as below:

Substance	Correction factor	No. of pump strokes			Measuring range			
Isobutyl acrylate	0.55	2			5.5 - 165 ppm			
Butyl acrylate	0.7	2				7 – 210 ppm		
Diethyl ketone (ppr	n)	5	27	60	170	346	513	
Tube 142L Reading (n=2)		10	30	50	100	200	300	

CORRECTION FACTOR:

Detector tubes are primarily designed to measure specific gases. But it is also possible to measure other substances of similar chemical properties with the aid of a correction factor or chart. Therefore, please make use of the correction factor/chart measuring ranges as a reference. For a more precise factor please contact your Gastec representatives.

DANGEROUS AND HAZARDOUS PROPERTIES:

Threshold Limit Value-Time Weighted Average by ACGIH (2022): 50 ppm Threshold Limit Value-Short Term Exposure Limit by ACGIH (2022): 150 ppm

INSTRUCTIONS ON DISPOSAL:

The reagent of the tube uses a small amount of hexavalent chromium. When disposing the tube regardless of whether it has been used or not, follow the rules and regulations of your local government.

WARRANTY:

If you have any questions regarding gas detection and quality of the tubes, please feel free to contact your Gastec representatives.

Manufacturer: Gastec Corporation 8-8-6 Fukayanaka, Ayase-City, Kanagawa 252-1195, Japan https://www.gastec.co.jp/ Telephone +81-467-79-3910 Facsimile +81-467-79-3979 IM00142LE4 Printed in Japan 23D1Z