GASTEC Instructions for No. 5Lb Sulphur Dioxide Detector Tube

FOR SAFE OPERATION:

Carefully read this manual and the instruction manual of your Gastec Gas Sampling Pump.

- 1. Use only Gastec detector tubes in a Gastec pump.
- 2. Do not interchange or use non-Gastec parts or components in Gastec's detector tube and pump system.
- 3. Using non-Gastec parts or components in Gastec's detector tube and pump system or using a non-Gastec detector tube with a Gastec pump or using a Gastec detector tube with a non-Gastec pump may damage your detector tube and pump system, or may cause serious injuries, or death to the end-user. It will also void all warranties, and guarantees regarding performance and data accuracy.

CAUTION: If you do not observe the following precautions, you may suffer injuries or damage the product.


- 1. When breaking the tube ends, keep away from eyes.
- 2. Do not touch the broken glass tubes, broken pieces and reagent with bare hand(s).
- 3. The sampling time represents the time necessary to draw the air sample through the tube. The tube must be positioned in the desired sampling area for the entire sampling time or until the flow finish indicator indicates the end of the sampling.

△ NOTES: For maintaining performance and reliability of the test results, observe the following.

- 1. Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
- 2. Use this tube within the temperature range of 0 40°C (32 104°F).
- 3. Use this tube within the relative humidity range of 20 80%.
- 4. This tube may be interfered with by the coexisting gases. Please refer to the table "INTERFERENCES" below.
- 5. If this tube samples the steel cylinder gas containing nitrogen or sulphur hexafluoride having a water vapour concentration of less than 0.1 mg/l or 100% carbon dioxide gas of 200 ml or more, the tube will show faint yellowish discolouration around the gas inlet of the tube.
- 6. The shelf life and storage condition of the tube are marked on the label of the tube box.

APPLICATION OF THE TUBE: Use this tube for detecting Sulphur dioxide in the air or in industrial areas and for determining the environmental atmospheric condition.

SPECIFICATION: (Because of Gastec's commitment to continued improvement, specifications are subject to change without notice.)



Detecting Layer

Measuring Range	0.05 - 0.1 ppm	0.1 - 0.2 ppm	0.2 - 5.0 ppm	5.0 - 10.0 ppm	
Number of Pump Strokes	8	4	2	1	
Stroke Correction Factor	1/4	1/2	1	2	
Sampling Time	1 minute per pump stroke				
Detecting Limit	0.01 ppm (n = 8)				
Colour Change	Yellowish green \rightarrow Yellow				
Reaction Principle	$SO_2 + BaCl_2 + H_2O \ \rightarrow \ BaSO_3 + 2HCl HCl + Base \ \rightarrow \ Chlorides$				

Coefficient of Variation: 10% (for 0.2 to 1.0 ppm), 5 % (for 1.0 to 5.0 ppm)

** Shelf Life: Please refer to the validity date printed on the tube box.

** Store the tubes in a dark and cool place.

CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE:

This tube is calibrated at 20°C and 1013hPa. The calibration gas is prepared at RH50%. If used in other conditions, please follow below correction guide.

Temperature: Humidity: Pressure:	No correction is required. No correction is required. To correct for pressure, use the formula below: Tube Reading (ppm) ×1013 (hPa)
	Atmospheric Pressure (hPa)

MEASUREMENT PROCEDURE:

- 1. For checking the leakage of the pump, insert a freshly sealed detector tube into the pump. Follow instructions provided with the pump operation manual.
- 2. Break tips off a fresh detector tube with the tube tip breaker in the pump.
- 3. Insert the tube into the pump inlet with the arrow (G>) on the tube pointing toward the pump.
- Make certain the pump handle is all the way in. Align the guide marks on the pump body with the guide marks on the handle.
- 5. Pull the handle all the way out until it locks at one pump stroke (100 mL). Wait one minute and confirm the completion of the sampling. Repeat the sampling procedure one more time.
- 6. For smaller measurements less than 0.2 ppm, repeat the above sampling procedure 2 or 6 more times until the stain reaches the first calibration mark. For measurements higher than 5.0 ppm, prepare a fresh tube and perform one stroke.
- 7. Read the concentration level at the interface where the stained reagent meets the unstained reagent.
- 8. If necessary, multiply the readings by the correction factors of the pump strokes and atmospheric pressure respectively.

INTERFERENCES:

Substance	Concentration	Interference	Interference gas only
Carbon monoxide, Nitric oxide		No	No discoloration
Carbon dioxide	100%	+	Yellow
Nitrogen dioxide	≧1 ppm	Unclear demarcation	Yellow
Hydrogen sulphide		No	No discoloration

This table of interference gases primarily expresses the interference of each coexisting gas in the concentration range, that is equivalent to the gas concentration. Therefore, the test result may show positive results due to other substances not listed in the table. If more information is needed, please contact us or our distributors in your territory.

DANGEROUS AND HAZARDOUS PROPERTIES:

Threshold Limit Value-Short Term Exposure Limit by ACGIH (2014): 0.25 ppm

INSTRUCTIONS ON DISPOSAL: The reagent of the tube does not use toxic substances. When disposing the tube regardless of whether it has been used or not, follow the rules and regulations of your local government.

WARRANTY: If you have any questions regarding gas detection and the quality of the tubes, please feel free to contact your Gastec representatives.

Manufacturer: Gastec Corporation 8-8-6 Fukayanaka, Ayase-City, Kanagawa 252-1195, Japan http://www.gastec.co.jp/ Telephone +81-467-79-3910 Fax +81-467-79-3979 IM005LbE2 Printed in Japan 14K1D