

GASTEC Instructions for No.127 o-Dichlorobenzene Detector Tube

FOR SAFE OPERATION :

Carefully read this manual and the instruction manual of your Gastec Gas Sampling Pump.

⚠ WARNING :

1. Use only Gastec detector tubes in a Gastec pump.
2. Do not interchange or use non-Gastec parts or components in Gastec's detector tube and pump system.
3. Using non-Gastec parts or components in Gastec's detector tube and pump system or using a non-Gastec detector tube with a Gastec pump or using a Gastec detector tube with a non-Gastec pump may damage your detector tube and pump system, or may cause serious injuries, or death to the end-user. It will also void all warranties, and guarantees regarding performance and data accuracy.

⚠ CAUTION : If you do not observe the following precautions, you may suffer injuries or damage the product.

1. When breaking the tube ends, keep away from eyes.
2. Do not touch the broken glass tubes, broken pieces and reagent with bare hand(s).
3. The sampling time represents the time necessary to draw the air sample through the tube. The tube must be positioned in the desired sampling area for the entire sampling time or until the flow finish indicator indicates the end of the sampling.

△ NOTES : For maintaining performance and reliability of the test results, observe the following.


1. Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
2. Use this tube within the temperature range of 0 - 40°C (32 - 104°F).
3. Use this tube within the relative humidity range of 0 - 90%.
4. This tube may be interfered with by the coexisting gases. Please refer to the table "INTERFERENCES" below.
5. The shelf life and storage condition of the tube are marked on the label of the tube box.

APPLICATION OF THE TUBE :

Use this tube for detecting o-Dichlorobenzene in the air or in industrial areas and for determining the environmental atmospheric condition.

SPECIFICATION :

(Because of Gastec's commitment to continued improvement, specifications are subject to change without notice.)



Measuring Range	2.5 - 300 ppm
Number of Pump Strokes	2
Stroke Correction Factor	1
Sampling Time	1.5 minutes per pump stroke
Detecting Limit	1 ppm (n = 2)
Colour Change	White → Light brown
Reaction Principle	$C_6H_4Cl_2 + I_2O_5 + H_2S_2O_7 \rightarrow I_2$

Coefficient of Variation : 10% (for 2.5 to 100 ppm), 5% (for 100 to 300 ppm)

****Shelf Life : Please refer to the validity date printed on the tube box.**

****Store the tubes in dark and cool place.**

CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE :

Temperature : Correct for temperature with the table below.

Tube Reading (ppm)	True Concentration (ppm)								
	0°C (32°F)	5°C (41°F)	10°C (50°F)	15°C (59°F)	20°C (68°F)	25°C (77°F)	30°C (86°F)	35°C (95°F)	40°C (104°F)
300	—	—	830	460	300	150	106	90	62
200	—	950	550	310	200	106	80	68	50
100	610	470	280	160	100	62	50	44	36
50	300	240	140	80	50	36	34	30	26
30	180	140	80	40	30	26	24	22	18
10	60	50	30	15	10	10	10	10	8
5	30	20	15	8	5	5	5	5	4


Humidity : No correction is required between 0 - 90% R.H.

Pressure : To correct for pressure, use the formula below

$$\frac{\text{Tube Reading}^* (\text{ppm}) \times 1013 (\text{hPa})}{\text{Atmospheric Pressure (hPa)}}$$

* This value is after other correction(s), if any, are applied.

MEASUREMENT PROCEDURE :

1. For checking the leakage of the pump, insert a freshly sealed detector tube into pump. Follow instructions provided with the pump operating manual.
2. Break tips off a fresh detector tube with the tube tip breaker in the pump.
3. Insert the tube into the pump inlet with arrow () on the tube pointing toward the pump.
4. Make certain the pump handle is all the way in. Align the guide marks on the pump body with the guide marks on the handle.
5. Pull the handle all the way out until it locks at one pump stroke (100 mL). Wait 1.5 minutes and confirm the completion of the sampling. Repeat the above sampling procedure one more time.
6. Read the concentration level at the interface where the stained reagent meets the unstained reagent.
7. If temperature correction is necessary, obtain the true concentration by using the temperature correction table.
8. If pressure correction is necessary, use the pressure correction formula.

INTERFERENCES :

Substance	Concentration	Interference	Changes colour by itself to
Carbon monoxide	≦ 0.1%	No	Light brown for whole layer at 0.1%
Acetylene, Ethylene, Hexane	≦ 0.2%	No	Light brown for whole layer at 0.2%
Alcohols, Ketones	≧ 1%	+	No discolouration
Esters	≦ 0.2%	No	Light brown for whole layer at 0.2%
Aromatic hydrocarbons		+	Light brown

This table of interference gases primarily expresses the interference of each coexisting gas in the concentration range, that is equivalent to the gas concentration. Therefore, the test result may show positive results due to other substances not listed in the table. If more information is needed, please contact us or Gastec representatives.

APPLICATION FOR OTHER SUBSTANCES :

Tube 127 can also be used for other substances as below.

Substance	Correction Factor	No. of Pump Strokes	Measuring Range
m-Dichlorobenzene	1.0	2	2.5 – 300 ppm
p-Dichlorobenzene	1.0	2	2.5 – 300 ppm

CORRECTION FACTOR :

Detector tubes are primarily designed to measure specific gases. But it is also possible to measure other substances of similar chemical properties with the aid of a correction factor or chart. Therefore, please make use of the correction factor/chart measuring ranges as a reference. For more precise factor please contact your Gastec representatives.

DANGEROUS AND HAZARDOUS PROPERTIES :

Threshold Limit Value-Time Weighted Average by ACGIH (2021) : 25 ppm

Threshold Limit Value-Short Term Exposure Limit by ACGIH (2021) : 50 ppm

INSTRUCTIONS ON DISPOSAL :

The reagent of the tube uses a small amount of hexavalent chromium. When disposing the tube regardless of whether it has been used or not, follow the rules and regulations of your local government.

WARRANTY :

If you have any questions regarding gas detection and the quality of the tubes, please feel free to contact your Gastec representatives.