

## Detector tube No. 115, 2-Butanol, Instruction Manual Correction

Gastec Corporation

We would like to apologize for the error discovered in the Detector Tube, No.115, 2-Butanol, Instruction Manual regarding the Temperature Correction.

We have corrected the error in the Temperature Correction.

●Details of the correction to the Instruction Manual:

Before the correction:

Temperature	0°C (32°F)	5°C (41°F)	10°C (50°F)	15°C (59°F)	20°C (68°F)	25°C (77°F)	30°C (86°F)	35°C (95°F)	40°C (104°F)
Correction Factor	1.8	1.55	1.3	1.15	1.0	0.9	0.8	0.78	0.75

After the correction:

Tube Reading (ppm)	True Concentration (ppm)								
	0°C (32°F)	5°C (41°F)	10°C (50°F)	15°C (59°F)	20°C (68°F)	25°C (77°F)	30°C (86°F)	35°C (95°F)	40°C (104°F)
150	–	–	300	181.5	150	126	126	115.5	108
100	–	300	175	121	100	84	84	77	72
50	120	80	65	60.5	50	42	42	38.5	36
20	30	28	26	24.2	20	16.8	16.8	15.4	14.4
10	15	14	13	12.1	10	8.4	8.4	7.7	7.2
5	7.5	7.0	6.5	6.0	5	4.2	4.2	3.9	3.6

We apologize for this error and thank you for your understanding.