

## Detector tube No. 117, Isoamyl alcohol, Instruction Manual Correction

Gastec Corporation

We would like to apologize for the error discovered in the Detector Tube, No. 117, Isoamyl alcohol, Instruction Manual regarding the Correction Table.

We have corrected the error in the Correction Table.

●Details of the correction to the Instruction Manual:

Before the correction:

Tube Reading (ppm)	True Concentration (ppm)				
	0°C (32°F)	10°C (50°F)	20°C (68°F)	30°C (86°F)	40°C (104°F)
300	–	420	300	150	100
150	490	240	150	90	70
100	340	170	100	70	50
70	250	120	70	50	40
50	160	80	50	40	30
30	80	50	30	25	20
20	50	30	20	15	13
10	20	15	10	9	6
5	10	8	5	4	3

After the correction:

Tube Reading (ppm)	True Concentration (ppm)									
	0°C (32°F)	5°C (41°F)	10°C (50°F)	15°C (59°F)	20°C (68°F)	25°C (77°F)	30°C (86°F)	35°C (95°F)	40°C (104°F)	
300	–	–	–	–	300	75	61	53	43	
150	–	–	–	–	150	65	55	50	43	
100	–	–	–	600	100	58	48	45	40	
70	–	–	–	300	70	50	42	38	34	
50	–	–	550	150	50	43	36	32	28	
30	–	375	120	55	30	28	27	22	19	
20	280	85	40	22	20	20	20	19	14	
10	20	13	12	11	10	10	10	8	8	
5	10	7	6	5	5	5	5	4	4	

We apologize for this error and thank you for your understanding.