

Detector tube No. 133L, Tetrachloroethylene, Instruction Manual Correction

Gastec Corporation

We would like to apologize for the error discovered in the Detector Tube, No.133L, Tetrachloroethylene, Instruction Manual regarding the Correction Factor.

We have corrected the error in the Correction Factor.

●Details of the correction to the Instruction Manual:

Before the correction:

Temperature	0°C (32°F)	5°C (41°F)	10°C (50°F)	15°C (59°F)	20°C (68°F)	25°C (77°F)	30°C (86°F)	35°C (95°F)	40°C (104°F)
Correction Factor	2.0	1.6	1.3	1.1	1.0	0.85	0.7	0.6	0.55

After the correction:

Temperature	0°C (32°F)	5°C (41°F)	10°C (50°F)	15°C (59°F)	20°C (68°F)	25°C (77°F)	30°C (86°F)	35°C (95°F)	40°C (104°F)
Correction Factor	2.92	2.18	1.84	1.42	1.0	0.77	0.6	0.55	0.46

We apologize for this error and thank you for your understanding.