

# GASTEC No.75N Instructions for tert-Butyl Mercaptan Detector Tube

## FOR SAFE OPERATION :

Carefully read this manual and the instruction manual of your Gastec Gas Sampling Pump.

### ⚠ WARNING :

1. Use only Gastec detector tubes in a Gastec Pump.
2. Do not interchange or use non-Gastec parts or components in Gastec's detector tube and pump system.
3. The use of non-Gastec parts or components in Gastec's detector tube and pump system or use of a non-Gastec detector tube with a Gastec pump or use of a Gastec detector tube with a non-Gastec pump may result in property damage, serious bodily injury, and death; voids all warranties; and voids all performance and data accuracy guaranties.

### ⚠ CAUTION : If you do not observe the following precautions, you may suffer injuries or damage to the product.

1. When breaking the tube ends, keep away from eyes.
2. Do not touch the broken glass tubes, pieces and reagent with bare hand(s).
3. The sampling time represents the time necessary to draw the air sample through the tube. The tube must be positioned in the desired sampling area for the entire sampling time or until the flow finish indicator indicates the end of the sample.

### △ NOTES : For maintaining performance and reliability of the test results, observe the following.


1. Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
2. Use this tube within the temperature range of 0 – 40°C (32 - 104°F).
3. Use this tube within the relative humidity range of 0 - 90%.
4. This tube may be interfered with by the coexisting gases. Please refer to the table "INTERFERENCES" below.
5. Shelf life and storage condition of the tube are marked on the label of the box of tube.

### APPLICATION OF THE TUBE :

Use this tube for the detection of tert-Butyl mercaptan in air or the industrial areas and environmental atmospheric condition.

### SPECIFICATION :

(Because of Gastec's commitment to continued improvement, specifications are subject to change without notice.)



Measuring Range	1.25 – 2.5 mg/m <sup>3</sup>	2.5 – 50 mg/m <sup>3</sup>	50 – 250 mg/m <sup>3</sup>
Number of Pump Stroke	2	1	1/2
Correction Factor	0.5	1	5
Sampling Time	1.5 minutes per pump stroke		45 seconds
Detecting Limit	0.5 mg/m <sup>3</sup> (n=2)		
Colour Change	Yellow → Pink		
Reaction Principle	tert-Butyl Mercaptan reacts with the reagent to form intermediate material which stains indicator pink		

**Coefficient of Variation : 10% (for 2.5 to 20 mg/m<sup>3</sup>), 5% (for 20 to 50 mg/m<sup>3</sup>)**

**\*\*Shelf Life : Please refer to the validity date printed on the box of tube.**

**\*\*Store the tubes in the cool and dark place.**

### CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE :

**Humidity :** Correct for humidity with the factor by the table below :

Relative Humidity (%)	0	10	20	30	40	50	60	70	80	90
Correction Factor	1.0	1.0	0.9	0.8	0.75	0.7	0.7	0.65	0.65	0.65

**Temperature :** Correct for temperature after humidity correction by the table below :

Concentration After Humidity Correction (mg/m <sup>3</sup> )	True concentration (mg/m <sup>3</sup> )								
	0°C (32°F)	5°C (41°F)	10°C (50°F)	15°C (59°F)	20°C (68°F)	25°C (77°F)	30°C (86°F)	35°C (95°F)	40°C (104°F)
50	95.0	82.2	66.3	59.4	50.0	50.0	40.0	37.5	35.0
(45)	85.5	74.0	59.6	53.5	45.0	45.0	36.0	33.8	31.5
40	76.0	65.8	53.0	47.5	40.0	40.0	32.0	30.0	28.0
30	57.0	49.3	39.8	35.6	30.0	30.0	24.0	22.5	21.0
20	43.0	32.9	26.5	23.8	20.0	20.0	16.0	15.0	14.0
10	18.0	16.4	13.3	11.9	10.0	10.0	8.0	7.5	7.0
5	7.5	7.0	6.6	5.9	5.0	5.0	4.0	3.8	3.5
2.5	4.5	4.1	3.3	3.0	2.5	2.5	2.0	1.9	1.8

**Pressure :** To correct for pressure, multiply the tube reading by  

$$\frac{\text{Tube Reading (mg/m}^3\text{)} \times 1013 \text{ (hPa)}}{\text{Atmospheric Pressure (hPa)}}$$

### MEASUREMENT PROCEDURE :

1. For checking the leakage of the pump, insert a fresh sealed detector tube into the pump. Follow instructions provided with the pump operating manual.
2. Break tips off the fresh detector tube with the tube tip breaker of the pump.
3. Insert the tube into the pump inlet with arrow (G) on the tube pointing toward the pump.
4. Make certain the pump handle is all the way in. Align the guide mark on the pump body with the guide mark on the handle.

5. Pull the handle all the way out until it locks at one pump stroke (100 mL). Wait 1.5 minutes and confirm the completion of the sampling.
6. For smaller measurements less than 2.5 mg/m<sup>3</sup>, repeat the above sampling procedure one more time until the stain reaches the first calibration mark. For measurements higher than 50 mg/m<sup>3</sup>, prepare a fresh tube and perform a half pump stroke.
7. Read concentration level at the interface where the stained reagent meets the unstained reagent.
8. If necessary, multiply the readings by the correction factors for humidity with the table and correct Tube Reading for temperature with the table to have True Concentration.
9. If necessary, multiply the readings by the correction factors of pump strokes and atmospheric pressure respectively.

#### INTERFERENCES :

Substance	Concentration	Interference	Changes colour by itself to
Hydrogen sulphide		+	Pink
Hydrogen phosphide		+	Pink
Mercaptans		+	Pink
Methane		No	No discolouration
Propane	≤30%	No	No discolouration
Cyclohexene	≤1000 (mg/m <sup>3</sup> )	No	No discolouration
Dimethyl sulphide	≤25 (mg/m <sup>3</sup> )	No	No discolouration

This table of interference gases primarily expresses the interference of each coexisting gas in the gas concentration range, that is equivalent to the gas concentration. Therefore, the test result may be given positive result by the other substances not listed in the table. For more information is needed, please contact us or Gastec representatives.

#### INSTRUCTIONS ON DISPOSAL :

The reagent of the tube does not use toxic substances. When disposing the tube regardless of whether it has been used or not, follow the rules and regulations of your local government.

#### WARRANTY :

If you have any questions regarding gas detection and quality of the tubes, please feel free to contact your Gastec representatives.

Manufacturer : Gastec Corporation  
 8-8-6 Fukayanaka, Ayase-City, Kanagawa 252-1195, Japan  
<http://www.gastec.co.jp/>  
 Telephone +81-467-79-3910 Facsimile +81-467-79-3979

IM0075NE1  
 Printed in Japan  
 17B1Z