

GASTEC No.1DL

Instructions for Carbon Monoxide Low Range Passive Dosi - Tube

FOR SAFE OPERATION :

Read this manual carefully before use.

⚠ CAUTION : If not observed, injuries to the operator or damage to the product may result.

1. When breaking the Passive Dosi-Tube, keep away from eyes.
2. Do not touch the broken glass tubes, pieces and reagent with bare hand(s).

△NOTES : For maintaining performance and reliability of the test result


1. Use this tube within the temperature range of 0 - 40°C (32 - 104°F).
2. Use this tube within the relative humidity range of 0 - 90%
3. This tube may be interfered by the coexisting gases. Please refer to the "INTERFERENCES".
4. Shelf life and storage conditions of the Passive dosi-tube are marked on the label of the box of tube.

APPLICATION OF THE TUBE :

Use of this tube for the detection of Carbon Monoxide in air or the industrial areas and environmental atmospheric condition.

SPECIFICATION :

(As a result of Gastec's commitment to continued improvement, specifications are subject to change without notice.)



Measuring Range	0.4 - 400 ppm - hour
Sampling Hours	0.5 - 24 hours
Detecting Limit	0.2 ppm (10 hours)
Color Change	Pale Yellow → Brown
Reaction Principle	Carbon Monoxide reduces sodium palladosulfite to liberate metallic palladium, which produces a brown stain. $CO + Na_2 Pd (SO_3)_2 \rightarrow Pd + CO_2 + Na_2SO_3$

**** Shelf Life : Please refer to the Validity Date printed on the box of tube.**


CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE :

Temperature : Temperature correction is not required.

Humidity : Humidity correction is not required.

Pressure : Pressure correction is not required.

MEASUREMENT PROCEDURE :



1. Break the tube at the score of the tube with Gastec Passive Dosi-Tube Holder No.710.
2. Set the Dosi-tube in the Tube Holder firmly inside the holder so the broken part is not appeared from the edge of the holder. Record the measurement starting time on the peel off numbered label in each box of the tube and put the label on the tube.
3. For personal sampling, put the dosi-tube holder to the shirt collar of the personel or workplace where the measurement is required. When the sampling is finished, record the time on the label of the tube.
4. Average gas concentration can be obtained from an hour to 24 hour sampling. 4 - 10 hours sampling term is recommended. Calculate actual sampling time and obtain the average gas concentration can be obtained by the following formula :

$$\text{Average Concentration} = \frac{\text{Dosi - Tube Reading (ppm \cdot hour)}}{\text{Actual Sampling Time (hour)}}$$

5. To protect the tube holder of shirt collar from dropping during operation, support the tube holder with string through a small hole of the tube holder.

INTERFERENCES :

Substance	Concentration	Interference	Change color by itself
Nitrogen dioxide	5 ppm or higher	Minus error	No discoloration by itself
Chlorine		No effect	No discoloration by itself
Hydrogen sulfide		Plus error	Discolor reddish brown

DANGEROUS AND HAZARDOUS PROPERTIES.

Threshold limit Value-Time Weighted Average by ACGIH (1998) : 25 ppm (7 - 8 hours)

DISPOSAL INFORMATION :

Reagent of the tube does not use toxic substance. On disposing the tube regardless of wheether used or unused, follow the rules and regulations of the local government.

WARRANTY :

If you have any questions regarding gas detection and quality of the tube, please feel free to contact your Gastec representatives.

Manufacturer : Gastec Corporation
8-8-6 Fukayanaka, Ayase-City, 252-1195, Japan
<http://www.gastec.co.jp/>
Telephone +81-467-79-3910 Facsimile +81-467-79-3979

IM011DLE1
Printed in Japan
05K1Z