GASTEC Instructions for Methanol Detector Tube

FOR SAFE OPERATION:

Carefully read this manual and the instruction manual of your Gastec Gas Sampling Pump.

⚠ WARNING:

- 1. Use only Gastec detector tubes in a Gastec Pump.
- Do not interchange or use non-Gastec parts or components in Gastec's detector tube and pump system.
- 3. The use of non-Gastec parts or components in Gastec's detector tube and pump system, or use of a non-Gastec detector tube with a Gastec pump, or use of a Gastec detector tube with a non-Gastec pump may result in property damage, serious bodily injury, and death; voids all warranties; and voids all performance and data accuracy guarantees.

⚠ CAUTION: If you do not observe the following precautions, you may suffer injuries or damage the product.

- 1. When breaking the tube ends, keep away from eyes.
- 2. Do not touch the broken glass tubes, pieces or reagent with bare hand(s).
- 3. The sampling time represents the time necessary to draw the air sample through the tube. The tube must be positioned in the desired sampling area for the entire sampling time or until the flow finish indicator indicates the end of the sample.

△NOTES: For maintaining performance and reliability of the test results, observe the following.


- Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
- 2. Use this tube within the temperature range of 0 40°C (32 104°F).
- 3. Use this tube within the relative humidity range of 20 90%.
- This tube may be interfered with by the coexisting gases. Please refer to the table "INTERFERENCES" below.
- 5. In less than 20% humidity atmosphere tubes will indicate lower reading.
- 6. Shelf life and storage condition of the tube are marked on the label of the box of tube.

APPLICATION OF THE TUBE:

Use this tube for detecting Methanol in the air or in industrial areas and for determining the environmental atmospheric condition.

SPECIFICATION:

(Because of Gastec's commitment to continued improvement, specifications are subject to change without notice.)



Measuring Range	20 - 40 ppm	40 - 1000 ppm	
Number of Pump Strokes	2	1	
Correction Factor	1/2	1.	
Sampling Time	2 minutes pe	er pump stroke	
Detecting Limit	15 ppm (n = 2)		
Colour Change	Pale vermilio	n → Pale blue	
Reaction Principle	$CH_3OH + Cr^{6+} + H_2SO_4 \rightarrow Cr^{3+}$		

Coefficient of Variation: 10% (for 40 to 200 ppm), 5% (for 200 to 1000 ppm)

** Shelf Life: Please refer to the validity date printed on the box of tubes.

** Store the tubes in a cool and dark place.

CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE:

Temperature: Correct for temperature by the table below:

Tube	True Concentration (ppm)								
Reading 0°C (32°F)	5°C (41°F)	10°C (50°F)	15°C (59°F)	20°C (68°F)	25°C (77°F)	30°C (86°F)	35°C (95°F)	40°C (104°F)	
1000	-	-	-	2500	1000	800	600	550	450
800	-	_	2900	1700	800	650	500	450	400
600		3500	1900	1250	600	460	400	350	320
400	3000	1700	1050	700	400	320	300	250	230
200	1000	500	400	300	200	175	160	145	130
100	300	200	150	130	100	90	80	70	70
40	100	80	60	50	40	40	40	35	30

Humidity: No correction is required between 20 - 90% R.H. **Pressure:** To correct for pressure, multiply the tube reading by

Tube Reading* (ppm) × 1013 (hPa)
Atmospheric Pressure (hPa)

* This value is after other correction(s), if any, are applied.

MEASUREMENT PROCEDURE:

- 1. For checking the leakage of the pump, insert a fresh sealed detector tube into the pump. Follow instructions provided with the pump operating manual.
- 2. Break tips off a fresh detector tube with the tube tip breaker of the pump.
- 3. Insert the tube into the pump inlet with arrow (**G>**) on the tube pointing toward pump.
- Make certain the pump handle is all the way in. Align the guide mark on the pump body with the guide mark on the handle.
- Pull the handle all the way out until it locks at one pump stroke (100 mL). Wait two minutes and confirm the completion of the sampling.
- For smaller measurements less than 40 ppm, repeat the above sampling procedure one more time until the stain reaches the first calibration mark.
- Read concentration level at the interface where the stained reagent meets the unstained reagent.
- If temperature correction is necessary, obtain the true concentration by using the temperature correction table. Afterwards multiply the correction factor of pump stroke if necessary.
- 9. If pressure correction is necessary, use the pressure correction formula.

INTERFERENCES:

Substance Concentration		Interference	Changes colour by itself to		
Alcohols		+	Pale blue		
Acetone	≥ 1000 ppm	+	No discolouration up to 1000 ppm		
Ethyl acetate	≤ 500 ppm	No	No discolouration up to 500 ppm		
Toluene	≦ 300 ppm	No	No discolouration up to 300 ppm		
Benzene	≦ 70 ppm	No	No discolouration		

This table of interference gases primarily expresses the interference of each coexisting gas in the gas concentration range, that is equivalent to the gas concentration. Therefore, the test result may give a positive result from other substances not listed in the table. If more information is needed, please contact us or your Gastec representatives.

APPLICATION FOR OTHER SUBSTANCES:

Tube 111L can also be used for the other substances as below:

Conversion Scale						
Ethylene chlorohydrine (ppm)	80 90 100	130	150	170	200	
Tube 111L Reading (n=3)	40 100 200	400	600	800	1000	

CORRECTION FACTOR:

Detector tubes are primarily designed to measure specific gases. But it is also possible to measure other substances of similar chemical properties with the aid of a correction factor or chart. Therefore, please make use of the correction factor/chart measuring ranges as a reference. For a more precise factor please contact your Gastec representatives.

DANGEROUS AND HAZARDOUS PROPERTIES:

Threshold Limit Value-Time Weighted Average by ACGIH (2023): 200 ppm Threshold Limit Value-Short Term Exposure Limit by ACGIH (2023): 250 ppm

INSTRUCTIONS ON DISPOSAL:

The reagent of the tube uses a small amount of hexavalent chromium. When disposing the tube regardless of whether it has been used or not, follow the rules and regulations of your local government.

WARRANTY:

If you have any questions regarding gas detection and quality of the tubes, please feel free to contact your Gastec representatives.

Manufacturer: Gastec Corporation 8-8-6 Fukayanaka, Ayase-City, Kanagawa 252-1195, Japan https://www.gastec.co.jp/ Telephone +81-467-79-3910 Facsimile +81-467-79-3979 IM00111LE5 Printed in Japan 23G1Z

