# GASTEC Instructions for Chlorobenzene Detector Tube

#### FOR SAFE OPERATION:

Carefully read this manual and the instruction manual of your Gastec Gas Sampling Pump.

## **⚠ WARNING:**

- 1. Use only Gastec detector tubes in a Gastec Pump.
- Do not interchange or use non-Gastec parts or components in Gastec's detector tube and pump system.
- 3. The use of non-Gastec parts or components in Gastec's detector tube and pump system or use of a non-Gastec detector tube with a Gastec pump or use of a Gastec detector tube with a non-Gastec pump may result in property damage, serious bodily injury, and death; voids all warranties; and voids all performance and data accuracy guaranties.

## ⚠ CAUTION : If you do not observe the following precautions, you may suffer injuries or damage to the product.

- 1. When breaking the tube ends, keep away from eyes.
- 2. Do not touch the broken glass tubes, pieces and reagent with bare hand(s).
- The sampling time represents the time necessary to draw the air sample through the tube.The tube must be positioned in the desired sampling area for the entire sampling time or until the flow finish indicator indicates the end of the sample.

## △NOTES: For maintaining performance and reliability of the test results, observe the following.


- Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
- 2. Use this tube within the temperature range of 0 40°C (32 104°F).
- 3. Use this tube within the relative humidity range of 0 90%.
- This tube may be interfered with by the coexisting gases. Please refer to the table "INTERFERENCES" below.
- 5. Shelf life and storage condition of the tube are marked on the label of the box of tube.

## **APPLICATION OF THE TUBE:**

Use this tube for the detection of Chlorobenzene in air or the industrial areas and environmental atmospheric condition.

## **SPECIFICATION:**

(Because of Gastec's commitment to continued improvement, specifications are subject to change without notice)



The Minimum Scale (0.5ppm) is not printed on the tube and is indicated as a Scale Line only.

Measuring Range	(0.5) - 10 ppm	10 – 57 ppm			
Number of Pump Strokes	3	1			
Correction Factor	1	5.7			
Sampling Time	1.5 minutes per pump stroke				
Detecting Limit	0.2 ppm (n=3)				
Colour Change	Yellow → Pale bluish purple				
Reaction Principle	C <sub>6</sub> H <sub>5</sub> Cl + PbO <sub>2</sub> + H <sub>2</sub> SO <sub>4</sub> → HCl HCl + Base → Chloride				

Coefficient of Variation: 10% (for 0.5 to 2 ppm), 5% (for 2 to 10 ppm)
\*\*Shelf Life: Please refer to the validity date printed on the box of tube.
\*\*Store the tubes in the refrigerator to keep at 10°C (50°F) or below.

etere the table in the reingerator to keep at 10 0 (601) or below

## CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE:

**Temperature:** Correct for temperature by the table below:

Tube Reading (ppm)	True Concentration (ppm)								
	0°C (32°F)	5°C (41°F)	10°C (50°F)	15°C (59°F)	20°C (68°F)	25°C (77°F)	30°C (86°F)	35°C (95°F)	40°C (104°F)
10	_	_	-	14.7	10	8.3	6.3	5.3	4.1
8	-	_	_	11.7	8	6.7	5.1	4.2	3.3
6	===	_	13.5	8.7	6	5	3.8	3.2	2.5
4	-	12.8	7.6	5.9	4	3.3	2.5	2.1	1.6
2	6.8	4.6	3.2	2.9	2	1.7	1.3	1.1	0.8
1	2.7	2.1	1.5	1.4	1	0.8	0.6	0.5	0.4
0.5	1.3	1	0.8	0.7	0.5	0.4	0.3	0.3	0.2

**Humidity:** No correction is required between 0 - 90% R.H. **Pressure:** To correct for pressure, use the formula below

Tube Reading\* (ppm) × 1013 (hPa)
Atmospheric Pressure (hPa)

\* This value is after other correction(s), if any, are applied.

### **MEASUREMENT PROCEDURE:**

- For checking the leakage of the pump, insert a fresh sealed detector tube into the pump.
   Follow instructions provided with the pump operating manual.
- 2. Break tips off a fresh detector tube with the tube tip breaker of the pump.
- 3. Insert the tube into the pump inlet with arrow ( G> ) on the tube pointing toward pump.
- Make certain pump handle is all the way in. Align guide mark on pump body with the guide mark on the handle.
- Pull handle all the way out until it locks at one pump stroke (100 mL). Wait 1.5 minutes and confirm the completion of the sampling. Repeat the above sampling procedure two more times
- 6. For measurements higher than 10 ppm, prepare a fresh tube and perform one pump stroke.
- Read concentration level at the interface where the stained reagent meets the unstained reagent.
- If temperature correction is necessary, obtain the true concentration by using the temperature correction table. Afterwards multiply the correction factor of pump stroke if necessary.
- 9. If pressure correction is necessary, use the pressure correction formula.

### INTERFERENCES:

Substance	Interference	Changes colour by itself to
Chlorine, Hydrogen chloride	+	Pale bluish purple
Trichloroethylene	+	Pale bluish purple
Tetrachloroethylene	+	Pale bluish purple

This table of interference gases primarily expresses the interference of each coexisting gas in the gas concentration range, that is equivalent to the gas concentration. Therefore, the test result may be given positive result by the other substances not listed in the table. For more information is needed, please contact us or Gastec representatives.

## **DANGEROUS AND HAZARDOUS PROPERTIES:**

Threshold Limit Value-Time Weighted Average by ACGIH (2021): 10 ppm

## **INSTRUCTIONS ON DISPOSAL:**

The reagent of the tube uses a small amount of lead. When disposing the tube regardless of whether it has been used or not, follow the rules and regulations of your local government.

### WARRANTY:

If you have any questions regarding gas detection and quality of the tubes, please feel free to contact your Gastec representatives.

Manufacturer: Gastec Corporation 8-8-6 Fukayanaka, Ayase-City, Kanagawa 252-1195, Japan https://www.gastec.co.jp/ Telephone +81-467-79-3910 Facsimile +81-467-79-3979 IM00126LE3 Printed in Japan 22C1Z