GASTEC Instructions for No.16 Phosgene Detector Tube

FOR SAFE OPERATION :

Read this manual and the instruction manual of your Gastec Gas Sampling Pump carefully.

⚠ CAUTION : If not observed, injuries to the operator or damage to the product may result.

- 1. When breaking the tube ends, keep away from eyes.
- 2. Do not touch the broken glass tubes, pieces and reagent with bare hand(s).

\triangle NOTES : For maintaining performance and reliability of the test result

- 1. Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
- 2. Use this tube within the temperature range of 0 40°C (32 104°F).
- 3. Use this tube within the relative humidity range of 20 80%.
- 4. This tube may be interfered by the coexisting gases. Please refer to the "INTERFERECES".
- 5. Shelf life and storage conditions of the tube are marked on the label of the box of tube.

APPLICATION OF THE TUBE :

Use this tube for the detection of Phosgene in industrial areas and environmental atmospheric monitoring.

SPECIFICATION :

(As a result of Gastec's commitment to continued improvement, specifications are subject to change without notice.)



Detecting Layer

Measuring Range	0.05 - 0.1 ppm	0.1 - 5 ppm	5 - 20 ppm			
Number of Pump Strokes	10	5	1			
Correction Factor	1/2	1	4			
Sampling Time	1 minute per pump stroke					
Detecting Limit	0.01 ppm (n = 10)					
Color Change	White → Yellow					
Reaction Principle	$COCI_2 + (CH_3)_2NC_6H_4CHO \rightarrow (CH_3)_2NC_6H_4CHCI_2 + CO_2$					
	$(CH_3)_2NC_6H_4CHCI_2 + (C_6H_5)_2NH \rightarrow \text{Reaction Product}$					

** Shelf Life : Please refer to the Validity Date printed on the box of tube. ** Store the tubes under dark and cool place.

CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE :

Temperature : To correct for temperature multiply the following correction factor.

[Temperature	°C	0	10	20	30	40
		(°F)	32	50	68	86	104
[Correction Fa	actor	1.8	1.3	1.0	0.95	0.9

Humidity : Humidity correction is not required.

Pressure : To correct for pressure, multiply the tube reading by Tube Reading (ppm) × 1013 (hPa)

Atmospheric Pressure (hPa)

MEASUREMENT PROCEDURE :

- 1. For leak checking the pump insert a fresh sealed detector tube into pump. Follow instructions provided with the pump operating manual.
- 2. Break tips off a fresh detector tube in the tube tip breaker of the pump.
- 3. Insert the tube securely into pump inlet with arrow G> on the tube pointing toward pump.
- 4. Make certain pump handle is all the way in. Align guide marks on pump body and handle.
- 5. Pull handle all the way out until it locks on 1 pump stroke (100ml). Wait 1.5 minute.Repeat the above sampling procedure 4 more times.
- 6. Read concentration at the interface of the stained-to-unstained reagent.
- 7. For detecting less than 0.1 ppm repeat the above sampling procedure 4 and 5 for 5 more times.
- 8. If atmospheric correction is needed, refer to the "Corrections for Temperature, Humidity and Pressure".

INTERFERENCES:

Substance	Concentration	Interference	Change color by itself
Hydrogen chloride	1/10 time or higher	Plus error	Produces yellow discoloration
Chlorine	1/2 times or higher	Plus error	Produces yellow discoloration
Nitrogen dioxide	1/5 times or higher	Plus error	Produces yellow discoloration

DANGEROUS AND HAZARDOUS PROPERTIES :

Threshold Limit Value-Time Weighted Average by ACGIH (1998): 0.1 ppm (7-8 hours)

DISPOSAL INSTRUCTION :

Reagent of the tube does not use toxic substances. On disposing the tube regardless of whether used or unused, follow the rules and regulations of the local government.

WARRANTY :

If you have any questions regarding gas detection and quality of the tubes, please feel free to contact your Gastec representatives.

Manufacturer : Gastec Corporation 8-8-6 Fukayanaka, Ayase-City, 252-1195, Japan http://www.gastec.co.jp/ Telephone +81-467-79-3910 Facsimile +81-467-79-3979 IM0016E1 Printed in Japan 05K1Z